


μEZGUI User's Manual

Covers the following products:

μEZGUI-1788-70WVM (Dev Kit)

μEZGUI-1788-70WVM-BA (Board Assembly)



FDI *Future Designs, Inc.*
Your Development Partner
996 A Cleaner Way, Huntsville, AL 35805

Copyright ©2013, Future Designs, Inc., All Rights Reserved

Table of Contents

1. Introduction	4
2. Block Diagram	4
3. Kit Contents (FDI PN: uEZGUI-1788-70WVM)	5
4. Useful links	5
5. Functional Description	5
6. Startup procedure	6
7. Demonstration Software Main Menu	7
8. Setting up a Slideshow	9
9. Setting up a Video	9
10. uEZ Doxygen online HTML documentation	9
11. uEZ Project Maker	10
12. Software	10
13. Configuring Rowley CrossWorks CrossStudio for ARM® for J-Link Flashing	11
14. Configuring IAR EWARM v6.30 for J-Link Flashing	12
15. Configuring Keil uVison 4 for J-Link Flashing	12
16. Functional Test Software	13
17. Board Layout	14
18. I/O Connector Descriptions	14
J3 - JTAG Connector	14
J12 - Tag Connect	15
J2 - MicroSD Socket	16
J1 - ISP Connector	18
J11 - Alternate Power and communication	18
PMOD Type 2A Connector J15 (loaded)	18
P1 – USB mini-AB port	18
P2 – USB Power Input 5VDC	19
J4 & J5 - Expansion Connectors	19
Expansion Connector Cable Details	23
19. Schematics	23
20. Temperature Range	23
21. ESD Warning	23
22. Real Time Clock Backup Time	23
23. Power Requirements	24
24. Mechanical Details	25
25. Dimension comparison between 70WVT and 70WVM models	26

Important Legal Information

Information in this document is provided solely to enable the use of Future Designs products. FDI assumes no liability whatsoever, including infringement of any patent or copyright. FDI reserves the right to make changes to these specifications at any time, without notice. No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of Future Designs, Inc. 996 A Cleaner Way, Huntsville, AL 35805.

For more information on FDI or our products please visit www.teamfdi.com.

NOTE: The inclusion of vendor software products in this kit does not imply an endorsement of the product by Future Designs, Inc.

© 2013 Future Designs, Inc. All rights reserved.

uEZ® is a registered trademark of Future Designs, Inc.

Microsoft, MS-DOS, Windows, Windows XP, Microsoft Word are registered trademarks of Microsoft Corporation.

Other brand names are trademarks or registered trademarks of their respective owners.

FDI PN: MA00040

Revision: 2-unreleased, 11/18/2014

Printed in the United States of America

1. Introduction

The μEZGUI-1788-70WVM-BA is designed to be used as an “off-the-shelf” Graphical User Interface (GUI) or Human Machine Interface (HMI) in a variety of end customer applications. The miniature, self-contained design is well suited to embed directly into your product or FDI offers prepackaged versions. FDI also offers low cost customization services for customer specific hardware, software or packaging applications at volumes of 500 units or more. The μEZGUI-1788-70WVM-BA is the stand-alone System-On-Module version and is priced at less than \$210.00 in volume.

2. Block Diagram




Figure 1 – μEZGUI-1788-70WVM-BA Block Diagram

3. Kit Contents (FDI PN: uEZGUI-1788-70WVM)

- uEZGUI-1788-70WVM-BA Capacitive Touch Screen Kit with LCD
- Segger Mini-JTAG Debugger and JTAG cable
- FDI JTAG Adapter Board
- 4 GB Micro SD card
- USB Cable (A to mini B)
- 5V 2A AC Power supply with USB connector
- Quick Start Guide
- Download Link for Rowley Crossworks IDE

4. Useful links

Complete Users Manuals, Schematics, and documentation are available on the Micro-SD card provided with the uEZGUI Kit and are also available from the following websites (please refer to the websites for the latest updates):

- Future Designs Support Page - <http://www.teamfdi.com/support/>
- uEZ Source Code, users manuals, and quickstart guides - <https://sourceforge.net/projects/uez/>
- Segger Mini-JTAG Debugger - <http://www.segger.com/cms/ilink-software.html>
- Rowley Crossworks IDE download for 30-day evaluation - <http://www.rowley.co.uk/arm/index.htm>

5. Functional Description


- LPC1788 120 MHz Cortex-M3 based Microprocessor
- 7.0" WVGA TFT LCD with I2C Capacitive Touch controller
- SDRAM 16MB, optional up to 32MB
- NOR FLASH 8MB, optional up to 16MB
- Internal 4KB EEPROM
- Serial EEPROM with Access Protection (optional)
- RTC – Real Time Clock (internal to LPC1788)
- Temperature Sensor
- 3-axis Accelerometer
- Optional 128Mbit Serial Flash
- Optional 802.11 Wi-Fi Module
- On-board Speaker/Buzzer
- Micro SD Card Socket for up to 8GB storage (SDHC supported up to 64 GB)
- Mini JTAG Connector
- Power-on Reset Generator - power-on reset supervisor, voltage monitor, & reset switch (SW1)
- Expansion Connectors for I/O and Peripheral access to customer specific applications

6. Startup procedure

The uEZ GUI kit comes with a pre-installed Micro SD card that contains files required for the slide show and videos to run. It also contains users' manuals, schematics, and documentation for the product.



Power is supplied via a USB cable and power supply provided in the kit. Connect the USB cable from the power supply to (P2) the mini B USB connector labeled 5V 1A min input only. Note that the other USB connector (P1) is for communications only and will not supply power to the unit. Also note that the minimum power requirement is 1.0A so most USB power sources, which are limited to 500mA max, will not adequately power this unit.



The following screens should appear once power has been applied to the kit:



At this point the unit is ready for software demonstrations and user operation.

By connecting the USB A to mini B cable to P1, the uEZGUI will also appear as a USB Flash Drive to the PC, allowing the user to read/write files directly to the Micro SD card.

7. Demonstration Software Main Menu

The Demonstration Software has the following options:

Slideshow

Selecting the slideshow icon will cause the Micro SD card to be read. This demonstration allows the user to select between several slideshow options such as “uEZGUI Family Overview”, “Demonstration Pictures”, “uEZ Software Overview”, “Modular Development Kit”, etc. Select the slideshow to view by touching the menu entry for it on the touch screen. By touching the screen during the slideshow, the menu overlay will appear. Select the play button (green) to begin the automated slide show. Touch the “||” button to pause the slideshow. The user can switch to the next slide by touching the “>” or “<” menu buttons, or by “dragging” the screen up or down. Click on the “X” to return to the main menu.

Video Player

Selecting the video player icon will cause the Micro SD card to be read. This demonstration allows the user to select between several example videos. Select the desired video to begin the automated playback of the video. The user can return to the menu at any time by tapping the screen. Click on the “return button” to return to the main menu. This demo takes advantage of being able to run the microSD card in full 4-bit SD mode at high speed. For lower resolution videos, the 640x480 and 800x480 resolution uEZGUIs can show informational text below the video.

The following programs appear under the “Apps” icon:

Accelerometer

Selecting this icon demonstrates the accelerometer feature by moving a simulated ball across the screen as the board is tilted along the X and Y axis. To return to the main menu touch the exit icon.

Time and Date

This feature displays the current time and date from the internal Real Time Clock (RTC). To change the time or date simply click on the section you want to change and increase or decrease using the up and down indicators. Once set an on-board super capacitor will back-up the time and date for several days (typically) if the unit is powered off. To return to the main menu touch the exit icon.

Temperature

Selecting this icon displays the temperature from the LM75 temperature sensor. To select between Celsius and Fahrenheit click the “C” or “F” to change. To return to the main menu touch the exit icon.

Exit the “Apps” icon to the main screen and the following programs are available

The following programs appear under the “Communications” icon:

Console

This option is only valid with either the uEZGUI-EXP1 or uEZGUI-EXP-DK attached with an active Ethernet connection. Select the icon to start a telnet server on port 23. Telnet to port 23 on the unit's IP address from a PC to access the standard serial console over a telnet connection.

The following programs appear under the “Settings” icon:

Brightness

Selecting the brightness icon shows a menu with color bars and a brightness adjustment slider. Move the slider up or down to adjust the brightness. There is a check box in this menu that can turn the screensaver demonstration on or off. By default it is turned off. When enabled, the screensaver will dim the screen and then display a moving uEZ logo icon all over the screen. When the screen is touched again, it will return back to the current menu view.

Functional Test is a step by step test of the following parameters:

- Speaker test
- LCD color test
- SDRAM size test
- Temperature
- EEPROM test
- NOR Flash Memory test

Draw

A very simple art program is provided. Use the touch screen to draw lines in the box to the right. Clicking on **Color** allows the color to be changed between various options. Hint – use black to erase. **Save** stores the graphic image as the file IMAGE.RAW on the Micro SD card. **Load** recalls the saved graphic image from the Micro SD card.

emWin Demo

If present, this runs a demonstration of various emWin graphical demos.

See <http://www.segger.com/emwin.html> for more details.

This example is available here for reference:

<http://www.segger.com/emwin-samples.html>

8. Setting up a Slideshow

The Slideshow demonstration loads and scrolls between images provided on a SD micro card. Images must be in 24 bit uncompressed Targa (.TGA) format. Adobe Photoshop and many other graphics programs can save images in this format. The images must be 800x480 and 11.11"x6.67" in size and use the file names WVSLIDExx.TGA where xx is 00 thru 99. (i.e. WVSLID01.tga, WVSLID02.tga, etc).

Images must be stored in a directory under /SLIDES. Edit the file "SLIDES.TXT" by adding a line in the following format: "<title>,<directory>". The field <title> is the text shown when selecting a slideshow. The field <directory> is the subdirectory in which the slides are found. The field <directory> must be 8 characters or less.

NOTE: Currently, the uEZ GUI allows selection of the top four entries of "SLIDES.TXT".

Place the pictures created above in the subdirectory listed in the "SLIDES.TXT" file. For example, entry "uEZGUI-1788-70WVM,UEZGUI" puts up a title of "uEZGUI-1788-70WVM" and loads the slides (WVSLID01.TGA to WVSLID08.TGA) from the directory /SLIDES/UEZGUI.

The Slideshow demonstration also allows for audio notes/narration to play back when a slide is shown. To use this feature, create audio files for each slide that you wish to have narrated. The files should be 22.05 KHz mono WAV files. Place the files inside the same directory as the slideshow. Each slide should have a corresponding WAV file with the exact same name. For example, for a slide named WVSLID03.TGA, the corresponding audio file will be named WVSLID03.WAV. During the Auto Play mode, the audio will be sync'ed with the slide progression and the viewing time between transitions is controlled by the length of the audio clip for each slide.

9. Setting up a Video

Refer to the "uEZ Video Conversion Guide" for details on converting a video for playback on a uEZGUI. The guide covers the video conversion process, as well as how to setup the video files on a microSD card for playback in the uEZ video player.

10. uEZ Doxygen online HTML documentation

μEZ® has built-in comment documentation that follows the Doxygen comment standard.

This standard allows for code comments and annotations to be written in a certain manner, and then compiled along with source code into HTML documentation.

FDI provides the pre-compiled HTML documentation at this link: <http://www.teamfdi.com/uez/docs/>

In the uEZ source code, "uEZ/uEZDoxyfile" is the main project file for the Doxygen generator. When Doxygen is recompiled, the new Doxygen files will be found here: uEZ\Docs\ Doxygen_Documentation.html

FDI will update the documentation roughly with each new μEZ® release or as new drivers are added to the system.

For more information, see the Doxygen website: <http://www.doxygen.org/>

11. uEZ Project Maker

FDI has provided a project maker to help create new projects for uEZGUI hardware.

The project maker is included in the uEZ source code download package and includes its own user's manual. This project maker can create demo projects using a very simple emWin example GUI, along with some basic peripheral functionality. The project maker greatly speeds up the development process for new applications. Example projects are ready to be compiled and programmed onto uEZGUI hardware using the included J-Link debugger, with no extra project configuration necessary.

12. Software

μEZ® takes its name from the Muses of Greek mythology. A Muse was a goddess who inspired the creation process for the arts and sciences. Like its ancient Greek namesake, the μEZ® platform inspires rapid development by supplying customers with an extensive library of open source software, drivers, and processor support - all under a common framework. μEZ® development works on the premise of "design once, reuse many times". This provides an open source standard for embedded developers to build upon and support. μEZ® allows companies to focus on innovation and on their own value-added applications while minimizing development time and maximizing software reuse.

The diagram below shows a typical embedded application stack. μEZ® has three primary categories of components that help simplify embedded application development:

1. **Operating System Abstraction Layer (μEZ® OSAL)**
2. **Sub-system drivers (μEZ® TCP/IP, μEZ® USB, μEZ® Driver)**
3. **Hardware Abstraction Layer (μEZ® HAL)**

Error! Objects cannot be created from editing field codes.

The selection of an RTOS can be one of the most daunting aspects of an embedded system development. With μEZ® the primary features of common multi-tasking operating systems are abstracted, thus easing the transition to an open source or low-cost RTOS. The μEZ® OSAL provides applications access to the following features in an OS-independent fashion:

- Pre-emptive multitasking
- Stack overflow detection
- Unlimited number of tasks
- Queues
- Semaphores (binary, counting, mutex)


The μEZ® sub-system drivers utilize the OSAL functions to provide protected access to the processor peripherals. The sub-system driver API functions are typically protocol layer interfaces (TCP/IP, USB, etc) designed as high-level access routines such as open, close, read, write, etc. where possible.

μEZ® is ideally suited for Embedded Systems with standard features such as:


- Processor and Platform BSPs (Board Support Packages)
- Real Time Operating System (RTOS)
- Memory Management
- NAND/NOR Flash
- SDRAM and DDR Memory
- TCP/IP stack
- USB Device/Host Libraries
- Mass Storage Devices
- LCD Displays with Touch Screen
- Input / Output Devices

13. Configuring Rowley CrossWorks CrossStudio for ARM® for J-Link Flashing

- 1) See the document “uEZ® Software Quickstart Guide” for details on how to download the uEZ® source code and setup the Rowley CrossWorks compiler.
(<http://www.teamfdi.com/uez/files/MA00015%20uEZ%20Software%20Quickstart%20Guide.pdf>)
- 2) Plug in the J-Link device into the PC and install any drivers as directed. The Segger J-Link drivers can be found at <http://www.segger.com/cms/jlink-software.html> with additional information at <http://www.segger.com/cms/development-tools.html>.
- 3) Plug in the J-Link's JTAG connector to the uEZGUI board at J3 with the JTAG adapter.
- 4) Select **Target** menu and choose **Targets**. The following list will appear to the right.




- 5) Right click on “Segger J-Link” and select Properties



- 6) If programming a blank LPC1788 part, select a Speed of 100. If the part has already been programmed, select a Speed of 1000.
- 7) Go back to menu **Target** and select “Connect Segger J-Link”
- 8) Compile the application and press F5 to download and start debugging.

14. Configuring IAR EWARM v6.30 for J-Link Flashing


The IAR tools do not require any special configuration for configuring the J-Link tools. To update IAR’s J-Link dll you just need to run Segger’s J-Link DLL Updated and select the IAR install you wish to update and click Ok.




15. Configuring Keil uVison 4 for J-Link Flashing

To configure Keil, use the following steps.

1. Click Flash from the Menu Bar and select Configure Flash Tools...
2. Click the Utilities Tab.
3. In the dropdown box for Use Target Driver for Flash Programming select the CORTEX-M/R J-LINK/J-Trace.



4. Click the Debug tab and select the same device for Use.



16. Functional Test Software

The Functional Test Software tests all the basic features of the uEZGUI-1788-70WVM-BA Kit as follows.

Functional Test is a step by step test of the following parameters:

- Accelerometer – Tests the presence of the accelerometer.
- EEPROM test - The EEPROM is tested for communication and integrity.
- LCD color test - Red, Green, and Blue are displayed in smooth bands to verify the LCD lines
- MicroSD – Looks for a Micro SD Card with the file “SLIDES/SLIDES.TXT”
- NOR Flash Memory test - basic test is performed to confirm read/write access.
- RTC – Sets the time and confirms the clock is running.
- SDRAM size test - Memory is sized and a basic test is performed to confirm read/write access.
- Speaker test - Tones are played and the User is asked to verify that they are heard.
- Temperature – the on board LM75B sensor is tested to be in a range of 20-30 C.

A final report of PASS or FAIL is displayed along with a list of any Skipped and Failed items.

17. Board Layout

The following figures illustrate the layout of the various components of the uEZGUI-1788-70WVM-BA. They are for reference only and are subject to change.




Figure 2 – uEZGUI-1788-70WVM-BA Component View

18. I/O Connector Descriptions

J3 - JTAG Connector

The uEZGUI-1788-70WVM-BA uses a reduced size JTAG connector based on a 0.050” Header. This smaller connector provides 100% of the functionality of the standard 20-pin JTAG connector, but utilizes 70% less board space. The connector is a standard part available from most major vendors.

Pin Number	Description	Pin Number	Description
1	3.3V	2	TMS
3	Ground	4	TCK
5	Ground	6	TDO
7	No Connect	8	TDI

9	No Connect	10	RESETn
---	------------	----	--------

The connector part number is PN: SAMTEC FTSH-105-01. Kits come with the SEGGER J-Link Lite Cortex-M shown below, and no adapter will be needed.




Figure 3 – SEGGER J-Link Lite Cortex-M 9-Pin JTAG with pinout (Rev 2.X+)

SEGGER and OLIMEX both provide adapters to convert the standard 20-pin JTAG to the new ARM 9-pin JTAG. The SEGGER adapter also allows for connecting TRST through the use of a solder bridge if needed. These adapters have female pins, and are only compatible with 20-pin JTAG units that have male pins. Both of these adapters come with the required cable.

- SEGGER 9-pin adapter - http://www.segger.com/jlink-adapters.html#CM_9pin
- OLIMEX 9-pin adapter - <https://www.olimex.com/Products/ARM/JTAG/ARM-JTAG-20-10/>

J12 - Tag Connect

The uEZGUI-1788-70WVM-BA also includes the ability to JTAG and program using the Tag-Connect TC2050-ARM2010 ARM 20-pin to TC2050 Adapter.

Adapter: <http://www.tag-connect.com/TC2050-ARM2010>

Cable with legs: <http://www.tag-connect.com/TC2050-IDC>

Cable with no legs: <http://www.tag-connect.com/TC2050-IDC-NL>

Holding clip for no-legs cable version: <http://www.tag-connect.com/TC2050-CLIP>




Figure 4 – Tag-Connect JTAG adapter, cables, and pinout for 10-pin TC2050

J2 - MicroSD Socket


When connected to the USB Host port on a PC, the uEZGUI-1788-70WVM-BA will appear as a USB Flash Drive to the PC, allowing the user to read and write files directly to the MicroSD card. The unit uses a MicroSD Socket for flexible mass storage capability.

Pin Number	Description
1	Micro SD DAT2
2	Micro SD DAT3
3	Micro SD CMD
4	3.3V
5	Micro SD SCLK
6	Ground
7	Micro SD DAT0
8	Micro SD DAT1


WARNING: The microSD card must only be removed using the spring loaded “push-pull” mechanism on the microSD socket. Improper forceful removal of the microSD card will result in permanent damage to the socket that is not covered under warranty. To insert the card, just push it into the socket until a “click” sound is heard.



Use your figure to gently push the card into the socket until it clicks.




At this point the microSD card is fully inserted. It should not fall out, even if the unit is shaken vigorously.



To remove the microSD card, press the card back into the socket until another “click” sound is heard, then release pressure on the card. At this point, the card should be partially ejected from the socket. Finally grab the card and gently pull to remove it. See the following pictures for proper micro-SD removal:

To remove the microSD card, gently push it into the socket again until it “clicks”, and then release your figure.




At this point, the microSD card should partially stick out of the socket.



Carefully grab the edges or sides of the microSD card and gently pull it out.



At this point the microSD card is fully removed from the socket.



J1 - ISP Connector

The uEZGUI-1788-70WVM-BA provides an ISP programming header. This header is designed to be utilized with the USB-ICP-LPC2K programmer from FDI. However the connector on the uEZGUI-1788-70WVM-BA is not directly compatible with the one used on the USB-ICP. This connector is a 1.25mm Hirose male, shrouded connector. The Hirose Part Number is: DF13A-6P-1.25H(20) (Digikey PN: H3371-ND). The pin out shown below is a direct, 1:1 connection to the USB-ICP-LPC2K programmer available from Future Designs, Digi-Key or Mouser.

Pin Number	Description
1	3.3V
2	Reset Input
3	ISP Entry
4	Ground
5	RXD
6	TXD

J11 - Alternate Power and communication

The uEZGUI-1788-70WVM-BA includes an alternate power and communication header. This header provides access to UART 2 or I2C Channel 2, as well as a 5V power input. This connector is a 1.25mm Hirose male, shrouded connector. The Hirose Part Number is: DF13A-6P-1.25H(20) (Digikey PN: H3371-ND).

Pin Number	Description
1	P0.10_TXD2_SDA2
2	5V Input
3	5V Input
4	Ground
5	Ground
6	P0.11_RXD2_SCL2

PMOD Type 2A Connector J15 (loaded)

The uEZGUI-1788-70WVT-BA includes a PMOD Type 2A (SPI) connection to an expansion board.

Pin Number	Description	Pin Number	Description
1	SPI Chip Select	7	Interrupt Request
2	SPI MOSI	8	Reset
3	SPI MISO	9	Optional I2C SCL
4	SPI Clock	10	Optional I2C SDA
5	Ground	11	Ground
6	3.3V	12	3.3V

P1 – USB mini-AB port

The uEZGUI-1788-70VVM has a mini-AB USB connector for host or device mode. By using a USB OTG adapter (with a mini-A plug) it will short the ID pin 4 to ground. This can be used for host mode detection in the application.

Pin Number	Description
1	5V
2	D-
3	D+
4	ID
5	Ground

P2 – USB Power Input 5VDC

The μEZGUI-1788-70WVM is normally powered via P2 with the included 5V USB Wall Supply. This power supply is only included in the development kit and is not included with the μEZGUI-1788-70WVM-BA. Note that the other USB connector (P1) is for communications only and will not supply power to the unit. Also note that the minimum power requirement is 1.0A so most USB power sources, which are limited to 500mA max, will not adequately power this unit.

Pin Number	Description
1	5V
2	No Connect
3	No Connect
4	Ground

J4 & J5 - Expansion Connectors

The μEZGUI-1788-70WVM-BA includes two expansion connectors that provide a wide variety of capabilities for user expansion, ranging from 10/100 Ethernet to USB Host, etc.

The tables below provide the pinout and signal names available on these connectors:

J4 Signal Details

Pin	Pin Name	Pin Description	
1	Ground (GND)		Power
2	P0.11_RXD2_SCL2_MAT3.1	P0[11] - General purpose digital Input/Output pin.	I/O
		RXD2 - Receiver input for UART2.	I
		SCL2 - I2C2 clock Input/Output (this is not an open-drain pin)	I/O
		MAT3[1] -Match output for Timer3, channel 1.	O
3	P0.10_TXD2_SDA2_MAT3.0	P0[10] - General purpose digital Input/Output pin.	I/O
		SDA2 - I2C2 data Input/Output (this is not an open-drain pin).	I/O
		MAT3[0] - Match output for Timer3, channel 0.	O
		TXD2 -Transmitter output for UART2.	O
4	P0.20_DTR1_MCICMD	P0[20] - General purpose digital Input/Output pin.	I/O
		DTR1 - Data Terminal Ready output for UART1	O
		SCL1 - I2C1 clock Input/Output (this is not an open-drain pin).	I/O
5	P0.19_DSR1_MCICLK	P0[19] - General purpose digital Input/Output pin.	I/O
		SDA1-I2C1 data Input/Output (this is not an open-drain pin).	I/O
		DSR1 - Data Set Ready input for UART1.	I
6	P0.22_MCIDAT0_RTS1	P0[22] - General purpose digital Input/Output pin.	I/O
		RTS1 - Request to Send output for UART1.	O
7	P0.17_CTS1	P0 [17] - General purpose digital Input/Output pin	I/O
		CTS1 - Clear to Send input for UART1.	I
		MISO - Master In Slave Out for SPI.	I/O

		MISO0 - Master In Slave Out for SSP0.	I/O
8	P0.16_RXD1	P0[16] - General purpose digital Input/Output pin.	I/O
		SSEL0 - Slave Select for SP0.	I/O
		RXD1 - Receiver input for UART1.	I
9	P0.15_TXD1	P0[15] - General purpose digital Input/Output pin.	I/O
		SCK0 - Serial clock for SSP0.	I/O
		TXD1 - Transmitter output for UART1.	O
		SCK - Serial clock for SPI.	I/O
10	Ground (GND)		Power
11	USB1_DM	P0[30] - General purpose digital Input/Output pin.	I/O
		USB_D- 1 - USB port 1 bidirectional D- line.	I/O
12	USB1_DP	P4[29] - General purpose digital Input/Output pin.	I/O
		USB_D+1 - USB port 1 bidirectional D+ line.	I/O
13	USB1H_PWRD	P4[26] -General purpose digital Input/Output pin.	I/O
		BLS0 - LOW active Byte Lane select signal 0.	O
14	USB1H_OVC	P4[24] - General purpose digital Input/Output pin.	I/O
15	USB1H_PPWR	P0[19] - General purpose digital Input/Output pin.	I/O
		CAP1[1] - Capture input for Timer 1, channel 1	I
		USB_PPWR1 - Port Power enable signal for USB port 1.	O
16	P0.9_I2STX_SDA_MOSI1_MAT2.3	I/O	I/O
		I2STX_SDA - I2S transmit data. It is driven by the transmitter and read by the receiver. Corresponds to the signal SD in the I2S-bus specification.	I/O
		MAT2[3] - Match output for Timer 2, channel 3	O
		MOSI1 - Master Out Slave In for SSP1.	I/O
17	P0.8_I2STX_WS_MISO1_MAT 2.2	P0[8] -General purpose digital Input/Output pin.	I/O
		I2STX_WS - I2S Transmit word select. It is driven by the master and received by the slave. Corresponds to the signal WS in the I2S-bus specification.	I/O
		MAT2[2] - Match output for Timer 2, channel 2	O
		MISO1 - Master In Slave Out for SSP1.	I/O
18	P0.7_I2STX_CLK_SCK1_MAT 2.1	P0[7] - General purpose digital Input/Output pin.	I/O
		I2STX_CLK - I2S transmit clock. It is driven by the master and received by the slave. Corresponds to the signal SCK in the I2S-bus specification.	I/O
		MAT2[1] - Match output for Timer 2, channel 1	O
		SCK1 - Serial Clock for SSP1.	I/O
19	P0.6_I2SRX_SDA_SSEL1_MAT2.0	P0[6] - General purpose digital Input/Output pin	I/O
		I2SRX_SDA - I2S Receive data. It is driven by the transmitter and read by the receiver. Corresponds to the signal SD in the I2S-bus specification.	I/O
		SSEL1 - Slave Select for SSP1.	I/O
		MAT2[0] - Match output for Timer 2, channel 0	O
20	P0.5_I2SRX_WS_TD2_CAP2.1	P0[5] - General purpose digital Input/Output pin.	I/O
		I2SRX_WS - I2S Receive word select. It is driven by the master and received by the slave. Corresponds to the signal WS in the I2S-bus specification.	I/O
		TD2 - CAN2 transmitter output.	O
		CAP2[1] - Capture input for Timer 2, channel 1	I
21	P0.4_I2SRX_CLK_RD2_CAP2.0	P0[4] -General purpose digital Input/Output pin.	I/O
		I2SRX_CLK - I2S Receive clock. It is driven by the master and received by the slave. Corresponds to the signal SCK in the I2S-bus specification.	I/O
		RD2 - CAN2 receiver input	I
		CAP2[0] - Capture input for Timer 2, channel 0	I
22	Ground (GND)		Power
23	RESET_INn	External reset input: A LOW on this pin resets the device, causing I/O ports and peripherals to take on their default states, and processor execution to begin at address 0. TTL with hysteresis, 5 V tolerant	I
24	RESET_OUTn	RSTOUT - This is a 3.3 V pin. LOW on this pin indicates LPC1788 being in Reset state	O
		P0[26] General purpose digital Input/Output pin.	I
		AD0[3] - A/D converter 0, input 3.	O

25	P0.26_AD03_AOUT_RXD3	AOUT - D/A converter output.	I
		RXD3 - Receiver input for UART3	I/O
26	P1.31_SCK1_AD0.5	P1[31] – General purpose digital Input/Output pin.	I/O
		SCK1 - Serial Clock for SSP1.	I/O
		AD0[5] - A/D converter 0, input 5	I
27	P1.17_ENET_MDIO	P1[17] - General purpose digital Input/Output pin.	I/O
		ENET_MDIO - Ethernet MIIM data input and Output	I/O
28	P1.16_ENET_MDC	P1[16] - General purpose digital Input/Output pin.	I/O
		ENET_MDC - Ethernet MIIM clock	O
29	Ground (GND)		Power
30	P1.15_ENET_REFCLK	P1[15] – General purpose digital Input/Output pin.	I/O
		ENET_REF_CLK/ENET_RX_CLK – Ethernet Reference Clock (RMII interface)/ Ethernet Receive Clock (MII interface)	I
31	P1.14_ENET_RX_ER	P1[14] –General purpose digital Input/Output pin.	I/O
		ENET_RX_ER - Ethernet receive error (RMII/MII interface)	I
32	3p3 volts	3.3 volts	Power
33	P1.10_ENET_RXD1	P1[10] – General purpose digital Input/Output pin.	I/O
		ENET_RXD1 - Ethernet receive data 1 (RMII/MII interface)	I
34	P1.9_ENET_RXD0	P1[9] - General purpose digital Input/Output pin.	I/O
		ENET_RXD0 - Ethernet receive data 0 (RMII/MII interface)	I
35	P1.8_ENET_CRSDV	P1[8] - General purpose digital Input/Output pin.	I/O
		ENET_CRSDV/ENET_CR – Ethernet Carrier Sense/Data Valid (RMII interface)/ Ethernet Carrier Sense (MII interface)	I
36	P1.4_ENET_TXEN	P1[4] - General purpose digital Input/Output pin.	I/O
		ENET_TX_EN - Ethernet transmit data enable (RMII/MII interface)	O
37	P1.1_ENET_TXD1	P1[1] - General purpose digital Input/Output pin.	I/O
		ENET_TXD1 - Ethernet transmit data 1 (RMII/MII interface)	O
38	P1.0_ENET_TXD0	P1[0] - General purpose Digital Input/Output pin.	I/O
		ENET_TXD0 - Ethernet transmit data 0 (RMII/MII interface)	O
39	Ground (GND)		Power
40	P2.10_EINT0_NMI	I/O - P2[10] - General purpose digital Input/Output pin. Note: LOW on this pin while RESET is LOW forces on-chip boot loader to take over control of the part after a reset.	I/O
41	P0.3_RXD0	P0[3] - General purpose digital Input/Output pin.	I/O
		RXD0 - Receiver input for UART0	I
42	P0.2_TXD0	P0[2] - General purpose digital Input/Output pin.	I/O
		TXD0 - Transmitter output for UART0	O
43	USBD_DP	USB_D+2 - USB port 2 bidirectional D+ line	I/O
44	USBD_DM	USB_D-2 - USB port 2 bidirectional D- line	I/O
45	USBD_VBUS	USB_PWRD2 - Power Status for USB port 2.	I
		VBUS - Monitors the presence of USB bus power. Note: This signal must be HIGH for USB reset to occur. I - AD0[4] - A/D converter 0, input 4	I
46	5volts (5V0)	5.0 Volts	Power
47	5volts (5V0)	5.0 Volts	Power
48	5volts (5V0)	5.0 Volts	Power
49	3p3 volts (3V3)	3.3 Volts	Power
50	3p3 volts (3V3)	3.3 Volts	Power

J5 Signal Details

Pin	Pin Name	Pin Description	
1	Ground (GND)		Power
2	P5.4_TXD0_OE_MAT3.3_TXD4 (LPC1788 only)	P5[4] – General Purpose digital Input/Output	I/O
		TXD0_OE - UART0 Transmitter Output Enable	O
		MAT3[3] – Match output for Timer 3, channel 3	O
		TXD4 – UART4 Transmit data	O

3	P5.3_RXD4_SCL0+ (LPC1788 only)	P5[3] – General Purpose digital Input/Output	I/O
		RXD4- UART4 receive data	I
		SCL0+ - I2C Clock for FM+ Operation	I/O
4	P5.2_MAT3.2_SDA0+ (LPC1788 only)	P5[3] – General Purpose digital Input/Output	I/O
		MAT3[2] – Match output for Timer 3, channel 2	O
		SDA0+ - I2C Data for FM+ Operation	I/O
5	P2.5_PWM1.6_U1.DTR_T2.MAT0	P2[5] – General Purpose digital Input/Output	I/O
		PWM1[6] – Pulse Width Modulator 1, channel 6 output.	O
		U1_DTR – Data Terminal Ready output for UART 1. Also UART 1 OE	O
		T2_MAT0 – Match output for Timer 2, channel 0	O
		TRACEDATA[0] – Trace data, bit 0	O
		LCD_LP – Line (STN) / Horizontal (TFT) synchronization pulse)	O
6	P2.3_PWM1.4_U1.DCD_T2.MAT2	P2[3] – General Purpose digital Input/Output	I/O
		PWM1[5] – Pulse Width Modulator 1, channel 5 output	O
		U1_DSR – Data Set Ready input for UART 1	I
		T2_MAT1 – Match output for Timer 2, channel 1	O
		TRACEDATA[1] – Trace data, bit 1.	O
		LCD_ENAB_M – STN AC bias drive or TFT data enable output	O
7	P1.7_MCIDAT1_PWM0.5	P1[7] – General Purpose digital Input/Output	I/O
		MCIDAT1 – Data line 1 for SD/MMC interface	I/O
		PWM0[5]-Pulse Width Modulator 0, output 5	O
8	P1.6_MCIDAT0_PWM0.4	P1[6] – General Purpose digital Input/Output	I/O
		MCIDAT1 – Data line 1 for SD/MMC interface	I/O
		PWM0[4]-Pulse Width Modulator 0, output 4	O
9	P1.5_MCIPWR_PWM0.3	P1[5] – General Purpose digital Input/Output	I/O
		MCIPWR – Power Supply Enable for external SD/MMC Power Supply	O
		PWM0[3]-Pulse Width Modulator 0, output 3	O
10	P1.3_MCICMD-PWM0.2	P1[3] – General Purpose digital Input/Output	I/O
		MCICMD – Command line for SD/MMC interface	I/O
		PWM0[2]-Pulse Width Modulator 0, output 2	O
11	P0.1_TD1_RXD3_RXD0	P0[1] – General Purpose digital Input/Output	I/O
		TD1 – Can1 transmitter output	O
		RXD3 – Receiver input for UART3	I
		RXD0 – Alternate UART0 receive data	I
12	P0.0_RD1_TXD3_TXD0	P0[0] – General Purpose digital Input/Output	I/O
		RD1 – Can1 receive input	I
		TXD3- Transmitter output for UART3	O
		TXD0 – alternate UART0 transmit data	O
13	5volts(5VO)	5.0 Volts	Power
14	Ground (GND)		Power
15	P0.13_USB2_UPLD_AD0.7	P0[13] – General Purpose digital Input/Output	I/O
		UPLD- USB port 2 Good Link indicator	O
		AD0[7]- A/D converter0, input 7	I
16	P0.12_USBPPWR2_AD0.6	P0[12] – General Purpose digital Input/Output	I/O
		AD0[6]- A/D converter0, input 6	I
17	P0.25_AD0.2_TXD3	P0[25] – General Purpose digital Input/Output	I/O
		AD0[2]- A/D converter0, input 2	I
		TXD3 – Transmitter output for UART3	O
18	TP_RL_Y2_P0.24_AD0.1	TP_RL_Y2 – Touch panel interface right side horizontal [Not Typically Supported]	
		P0[24] - General Purpose digital Input/Output	I/O
		AD0[1] – A/D converter0, input 1	I
19	TP_RL_X1_P0.23_AD0.0	TP_RL_X1 – Touch Panel left side horizontal [Not Typically Supported]	
		P0[23] - General Purpose digital Input/Output	I/O
		AD0[0] – A/D converter0, input 0	I
20	Ground (GND)		Power

Expansion Connector Cable Details

The maximum length for the expansion connector cables is as follows:
 General Purpose IO, TTL, Serial, etc = 6" recommended maximum, 8" absolute maximum
 Ethernet, high-speed IO, etc = 3" recommended maximum, 4" absolute maximum

The following table provides example part numbers for the expansion cables:

Description	Mfg	Mfg PN	Digi-Key Pn
3" 20-pin 0.5mm	Molex	21020-0209	WM10226-ND
6" 20-pin 0.5mm	Molex	21020-0215	WM10218-ND
3" 50-pin 0.5mm	Molex	21020-7650	WM10231-ND
6" 50-pin 0.5mm	Molex	21020-0548	WM10223-ND

Note: These lengths are only recommendations. The actual lengths utilized will be dependent on the expansion board circuitry, layouts and general environment of the application. It is up to the customer to test and validate the functional operation and use of the expansion connectors.

19. Schematics

Please see the FDI website at <http://www.teamfdi.com/support/touch-screen.php#uezgui-1788-70wvm> for support documentation.

20. Temperature Range

uEZGUI-1788-70WVM-BA without LCD: -40°C to +85°C

uEZGUI-1788-70WVM-BA with Microtips UMSH-8596MD-24T LCD: -20°C to +70°C

21. ESD Warning



The uEZGUI-1788-70WVM-BA kit is shipped in a protective anti-static package. The kit must not be subjected to high electrostatic potentials. Damage may occur to the boards that will not be covered under warranty. General practice for working with static sensitive devices should be followed when working with the kit.

22. Real Time Clock Backup Time

The uEZGUI's Real Time Clock is backed up with a Seiko Super Capacitor to allow the time to be preserved when external power is removed. The calculated backup time is shown below.

Super Capacitor	Typical Voltage	Stop Voltage	Maximum Current	Typical Backup Time
XH414HG	3.0 V	2.0 V	1μA	18 hrs

23. Power Requirements

Power is supplied into the power-only USB connector (P2) via a power supply provided in the kit. The power supply provides 5VDC output at 1.2A (min) and has input voltage range of 100-240VAC with standard U.S. 2-prong plug. The following typical power requirements were measured at room temperature with LPC1788 at 120MHz clock rate:

Voltage	Booted at the uEZ Demo Screen	Observed Max (video playback)
5V	790 mA	880 mA

The following measurements were taken with a GainSpan GS1011MIP Wi-Fi module loaded on the board and turned on and connected to an access point.

Voltage	Observed Max (Wi-Fi & video)	Maximum allowed
5V	1100 mA	Up to 2A through uEZGUI power connectors

- The uEZGUI is capable of providing a maximum of 100mA of 3.3V power for “external use” over the expansion connectors. If more than 100mA of 3.3V is needed for an expansion board:
 - Then the primary power input (i.e. 5V) should be located on the expansion board rather than on the uEZGUI.
 - The expansion board should be designed with a separate 3.3V voltage regulator.
 - Ensure the 3.3V voltage rails of the uEZGUI & Expansion Board are not connected together.
 - The uEZGUI should be powered using 5V from the Expansion Board over the 70 pin breakout, instead of powering the Expansion Board from the uEZGUI unit.
- The uEZGUI-1788-70WVM may also optionally be powered via the following connectors;
 - Alternate Power/Communication Connector, J11, with a maximum of 2A 5V input
 - Expansion Connector(s) J4 and/or J5 – refer to the expansion connector section for details

24. Mechanical Details

The following illustrations show the mechanical details of the μEZGUI-1788-70WVM-BA PCB




Figure 6 –Mechanical Layout Dimensions (Component View)

25. Dimension comparison between 70WVT and 70WVM models

